INSTALLATION

APEX BULLET ENDCAPS



The Apex Bullet Endcaps are designed to provide an aerodynamic contour to the ends of the Apex box awning.

COMPONENT CHECK LIST COMPONENT QTY 2 3 4 1 Endcap, LH 2 Endcap, RH 3 Screw, HWH, Self Drilling #10 x 5/8 4 Screw, PPH, Self Drilling 4 #10 x 1 1/4 2 RTA050

- 1. Position the endcap on the end of the awning. Drill two (2) 9/64" pilot holes in the end plate to match the mounting holes in the endcap.
- 2. Attach endcap using two (2) each #10 x 5/8 hex Self Drilling Screw washer head self-drilling screws.
- 3. Attach the endcap to the coach roof using one (1) #10 x 1 1/4 self-drilling screw.



