



DO NOT DISCARD THIS DOCUMENT!

THIS DOCUMENT MUST BE DELIVERED TO THE CONSUMER AT TIME OF PURCHASE.

LONGITUDE



Before operating the awning, carefully review the Owner's Manual. The manual contains important safety information, detailed operating instructions, common maintenance procedures and other useful information.

	<p>← 1. Scan the QR Code</p> <p>2. or go to www.carefreeofcolorado.com/longitude</p> <p>3. Click on the "Technical Documentation" tab to review, download and/or print a copy of the Owner's Manual.</p>	<u>Unique Product Identification</u>
--	--	--------------------------------------

GENERAL OPERATION

WARNING Awnings are designed to provide shade and protection from the sun. The effects of wind and rain on an awning are unpredictable and can cause severe damage to the awning and/or the vehicle. If wind or extended periods of rain are expected, roll up the awning.

NOTICE It is recommended that if leaving the RV unattended for a length of time, retract the awning to avoid unexpected climate conditions.

WARNING Keep all sources of heat and flame away from the awning canopy. Fabric is not fire-proof and can burn if left in contact with any flame or heat source.

WARNING Do not use a 110V power source for the emergency override procedure! Doing so will permanently damage the awning! Do not use the emergency override without following the directions given in the owner's manual.

CAUTION Use care when adjusting the pitch as the awning may move abruptly.

NOTICE Do not operate the awning with the individual arm pitches set at more than three (3) positions different between the left and right arm. Damage to the arms and canopy can occur if the awning is retracted with the arms uneven.

NOTICE For awnings 12' or less: Before retracting the awning, the individual arm pitches must be set equally. Damage to the arms and canopy can occur if the awning is retracted with the arms uneven.

CALIFORNIA PROPOSITION 65

WARNING This product contains chemicals known to the state of California to cause cancer or birth defects or other reproductive harm. California's Proposition 65 requires this warning to be given to customers in the state of California.

QUICK START OPERATION

To extend the awning: Press and hold the switch in the OUT (extend) position until the awning is in the desired position.

To retract the awning: Press and hold the switch in the IN (retract) position until the awning is closed.

TO ADJUST THE PITCH (refer to Warnings and Cautions above)

1. Extend the awning
2. Hold on to the awning arm to keep it steady while adjusting the pitch.
3. Press in the pitch adjustment pins located on the scissor arm.
Tip: Applying LIGHT pressure on the arm will decrease the force required to press the pitch adjustment pins.
4. Slide the scissor arm to the desired setting; towards the coach for a lower pitch; away from the coach for a higher pitch.

It is strongly recommended that repairs and/or service not described in the owner's manual be performed by trained technicians at your Authorized Carefree Dealer. Work performed by non-authorized persons or businesses may void warranty.